

# BrewGenie

## Setting Up BrewGenie with your Smartphone

Before your first time use, search for “ezpro” in Google Play store or Apple App store and download EZPro app to your smartphone. To register BrewGenie with your smartphone:

1. Connect AC plug to an outlet and make sure the power switch on the left side is ON. If the Connect LED blinks blue, press the **Menu** button once, blinking will stop.
2. Go to your smartphone Settings and make sure Bluetooth is turned on.
3. Open **EzPro** app and press **Register a new device** icon, smartphone begins scanning for bluetooth device.
4. Press and hold the **Menu** button on BrewGenie, release button when the Connect LED blinks blue.
5. Alternatively, you can use the power switch on the left side of BrewGenie to begin registration:
  - turn off BrewGenie
  - wait for 10 seconds
  - turn on BrewGenie
  - the connect LED blinks blue indicating BrewGenie is ready to register to a smartphone.
6. When a BrewGenie is found, a control icon is displayed.
7. If a control icon is not displayed in 60 seconds, close **EzPro** app and go back to step 3 to repeat registration process.
8. For iOS device: An iOS device and BrewGenie are registered and linked automatically.
9. For Android device: Close the **EzPro** app and reopen. Android device and BrewGenie will be registered and linked.
10. Press Setting to program BrewGenie’s name and operation scripts, such as auto mode, time to begin brewing, time to send set up message for next brewing, notification when brewing, aroma (to brew 1 to 4 cups), and keep warm time.
11. Enter the weight of coffee beans/ground coffee in inventory.
12. Press the Save icon to save coffee brewing scripts.



Register a new device

Scanning....

Ready to add device. Press and hold the Menu button, release button when the blue Connect LED is lit.



Save

Device name: Coffee

Auto



Begin brewing

07:15 AM

Notify setup

07:00 PM

Notify when brewing



Aroma



Keep warm

30 Minu



## Brewing Coffee

There are 3 ways to begin brewing coffee:

### 1. Using a Smartphone Manually

- Open the **EzPro** app and press the Coffee icon to begin brewing immediately.
- Smartphone and BrewGenie must be in-Range
- An alerting message and tones from smartphone if no water is in the tank. Auto/Brew LED blinks red fast. Brewing will stop.

### 2. Auto Brewing

- Open **EzPro** app and press the Setting icon, brewing scripts are displayed.
- Change scripts as required, select Auto mode. press the **Save** icon.
- An alerting message and tones from smartphone if no water is in the tank. Auto/Brew LED blinks red fast. Brewing will stop.
- Your smartphone can be out of range when brewing begins.
- BrewGenie will begin brewing per scripts.
- When brewing begins, your smartphone will play “Brewing coffee” alerting message and alerting tone/music.
- Estimated amount of coffee used is deducted from coffee inventory.



Warning: no water



### 3. Brewing without a Smartphone

A coffee brewing script is preloaded in factory. Or, you can reprogram brewing scripts using a smartphone. A smartphone is not required to begin coffee brewing.

- Press the **Menu** button and if you have programmed begin brewing time, Auto/Brew LED emits steady green. BrewGenie begins brewing coffee per schedule and scripts.
- If no water in the tank, Auto/Brew LED blinks red fast as a warning signal. Brewing will stop.
- When Auto/Brew LED emits steady red light. BrewGenie begins brewing coffee immediately per script.
- At the end of brewing, Auto/Brew LED blinks red to indicate in keep warm mode.

Save

### Monitor Coffee Bean/Ground Coffee Inventory

BrewGenie can estimate your usage of coffee beans/ground coffee. When inventory is low, a reminder is displayed on your smartphone. If it is set up with an online store or a local store, a discount coffee bean/ground coffee coupon will be displayed. For better estimation of your coffee bean/ground inventory, please enter the weight of each package received.

Inventory

0 pound

0 oz

Receive

+ lb

+ oz

Total


0 pound

0 oz

Factory default

Remove the device

Linked



### LED Indicators

#### 1. Auto/Brew LED:

- Red, steady: Brewing coffee
- Red, blinking: Keep warm after coffee brewing
- Red, fast blinking: no water warning.
- Green, steady: Auto mode, to begin brewing per scripts.

#### 2. Aroma/Connect LED:

- Blue, steady: BrewGenie is linked to a smartphone
- Blue, blinking: BrewGenie is ready to be found and registered to a smartphone
- Red, steady: In Aroma mode for brewing 1 to 4 cups, when not linked to a smartphone

App Store is a service mark of Apple Inc.

Google Play is a trademark of Google Inc.

Due to continue design and quality improvements, the EzPro app screen shots may look different from the pictures.  
Smartphone not included.

Coffee beans/ground coffee not included.

## **Important Safety Instructions**

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electrical shock and/or injury to persons, including the following:

1. Read and understand all instructions.
2. Follow all warnings and instructions marked on the product.
3. Do not touch hot surfaces. Use handles or knobs.
4. To protect against fire, electric shock and injury to persons, do not immerse cord, plugs or appliance in water or other liquid.
5. Not intended for use by children.
6. Close supervision is necessary when any appliance is used near children. Keep appliance out of reach of children.
7. Burns can occur from touching hot plate, or hot water. Exercise caution.
8. Do not place this product on an unstable cart, stand, or table. Serious damage may result if the product falls.
9. Unplug appliance from outlet as soon as you stop using it over a prolonged period and when you clean it. Allow to cool before putting on or taking off parts, before cleaning the appliance and before storing.
10. All appliance are subject to stringent quality control. Practical tests using appliance taken at random are conducted and this may explain any slight marks or coffee residue showing prior to use.
11. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.
12. To reduce the risk of injury, do not drape cord over the counter top or table top where it can be pulled on by children or tripped over unintentionally.
13. Do not let cord hang over edge of table or counter or touch hot surfaces.
14. The use of accessory attachments not recommended by the manufacturer may result in fire, electric shock, or injury to persons.
15. Do not use outdoors.
16. Do not place on or near a hot gas or electric burner, or in a heated oven.
17. To disconnect the appliance, turn the power switch on the left side to "OFF", then remove plug from wall outlet.  
Do not yank cord, instead grasp plug and pull to disconnect.
18. Do not pour liquids other than water into the water tank.
19. Protect the appliance against humidity and freezing.
20. This appliance is for household use only.
21. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capacities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
22. If this product does not operate normally, see the "*In Case of Difficulty*" section in this owner's manual. If you cannot resolve the problem, or if the product is damaged, refer to the "*Limited Warranty*" section of this owner's manual. Opening the product or reassembling it incorrectly may expose you to dangerous voltages or other risks, and will void the warranty.
23. For glass carafe:
  - The glass carafe is designed for use only with this appliance. It must never be used on a range top.
  - Do not set a hot carafe on a wet or cold surface.
  - Do not use a crack carafe or a carafe having a loose or weaken handle.
  - Do not clean carafe with harsh cleansers, steel wool pads, or other abrasive materials.
  - Do not use the carafe over an open flame, on an electric stovetop, or in an oven (microwave or not).

## **SAVE THESE INSTRUCTIONS**

# In Case of Difficulty

If your BrewGenie does not work properly, try the following suggestions before seeking repair assistance.

Problem	Possible cause	Solution
The coffee is not brewing	Unit unplugged	Plug unit in
	Power switch turned off	Turn power switch(on left side) on
	No water in tank	(1) Check water tank; (2) Use a smartphone to control BrewGenie, no-water warning is displayed.
	The filter basket is not properly inserted	Insert filter basket correctly
	The carafe is not placed correctly on the warming plate	Place carafe correctly on warming plate
The filter basket overflows	The filter basket is not properly inserted	Insert filter basket correctly
	The BrewGenie cover is not closed	Close BrewGenie cover
	The carafe is not placed correctly on the warming plate	Place carafe correctly on warming plate
	The carafe lid is not on carafe	Place lid on the carafe
The grounds are in the coffee	The filter and basket are not properly inserted	Insert filter and basket correctly
BrewGenie is not linked when EzPro app is open	Smartphone is out of range	Bring smartphone closer to BrewGenie
	EzPro is open on another smartphone	Close EzPro on another phone. BrewGenie is linked to only smartphone each time.

## Resetting BrewGenie

If you have difficulty operating BrewGenie with your smartphone, try the following suggestions.

1. Remove all active smartphone apps and reopen them.
2. If problem not resolved, power off your smartphone and power on again.
3. Power off BrewGenie, wait for 10 seconds, and power on again.
4. Open EzPro app, press Setting icon, scroll down to set BrewGenie to **Factory Default** and/or **Remove the Device**. Follow instructions to register BrewGenie again.

## Limited Warranty

This warranty applies only to products purchased and used in the United States. Any defect in materials or workmanship is covered for one year from the date of purchase.

If we repair your product, we may use new or reconditioned replacement parts. If we choose to replace your product, we may replace it with a new or reconditioned one of the same or similar design. The repair or replacement product will be warranted for either (a) 90 days, or (b) the remainder of the original one year warranty period whichever is longer.

You must prepay all shipping and handling costs. When sending your product for repair service, include your name, address, handling costs, and a description of the problem. Send all these to:

Fanstel Corp. Attn: Warranty Repair  
7466 E.Monte Cristo Ave. Scottsdale AZ 85260